Rectifier Monitoring

Fundamentals Course Period 7 Instructor: Josh Brewer



FOR IMMEDIATE RELEASE

Wednesday, January 7, 2015

Pipeline Corrosion Monitor Pleads Guilty to Pipeline Safety Violations and False Statements

Randy Jones, 44, a former corrosion coordinator for Shell Pipeline Company L.P. (Shell), pleaded guilty in Milwaukee today to failing to conduct bi-monthly voltage readings and an annual survey of a pipeline used to transport jet fuel in violation of the Pipeline Safety Act (PSA) and making a false statement to the Pipeline and Hazardous Material Safety Administration (PHMSA).

Jones, a resident of Louisiana, pleaded guilty to knowingly failing to conduct required safety test between January and December 2011 and submitting false data to PHMSA. The violations were in connection with a pipeline owned by Shell that delivered commercial aviation jet fuel to General Mitchell International Airport in Milwaukee, Wisconsin. In January 2012 a hole was discovered in the pipeline at Mitchell Airport after jet fuel began showing up in soil surrounding the airport and in nearby Wilson Creek. Fuel eventually reached and melted asphalt on airport property. Shell reported that approximately 9,000 gallons of jet fuel was released. The response and cleanup cost for the spill was approximately \$19.3 million.

Jones was employed by Shell from 1992 through 2012. From 2010 until 2012, Jones was employed as a corrosion coordinator and was responsible for Shell pipelines servicing Mitchell and Chicago O'Hare airports. Jones failed to conduct the required testing for 2011 and when advised of an audit by PHMSA scheduled for December 2011, he submitted false data indicating the required test had been conducted.

Consistent with requirements of the PSA, which establishes standards for the safe operation of the hazardous materials in pipelines, buried or submerged metal pipelines must be protected to prevent corrosion. This involves the use of a device called a rectifier which applies a negative current to soil near the pipeline to keep corrosion away from the pipe. The operator of the pipeline is required to conduct bi-monthly readings of the voltage generated from a rectifier and conduct an annual survey of the pipeline to insure that the pipeline is adequately protected from corrosion. PHMSA is the primary agency responsible for regulating and enforcing the PSA.

Objective of Presentation

- Familiarize everyone with components of Rectifiers
- <u>Understand</u> workings of components
- Understand the Why, What, How, and When of Rectifier Monitoring

What is a Rectifier?

 Rectifier converts or <u>rectifies</u> alternating current (AC) to direct current (DC)

DC current then flows to groundbed - then to structure needing cathodic protection

Samples of Rectifiers









Samples of Rectifiers







Basic Electric - Rectifying AC





Header Cables

Negative cable connected to the structure
Positive cable hooked to the groundbed





Basic Components of a Rectifier

- Circuit Breaker
- Transformer
- Rectifying Elements
- Accessory Equipment

Standard Rectifier Unit



TYPICAL AIR COOLED RECTIFIER

FIGURE 7-17

- Standard Rectifier
 - Circuit Breaker
 - ♦ Output Fuse
 - Tap Setting Controls
 - Dual Meter Amps and Volts
 - Meter Switch
 - Rectifier Output Terminals

Circuit Breaker

Primary Function

- provide overload protection
 for the circuit in which it's
 installed
- serves as an on-off switch for the rectifier



FULLY MAGNETIC CIRCUIT BREAKER

FIGURE 7-13

Standard Transformer



Primary Function

- used to "step up" or "step down" voltage
- isolate voltage from source

Rectifying Elements

- Allow current to flow in only ONE direction
 Two Types of Postifying Elements
- Two Types of Rectifying Elements
 - Selenium Cell
 - Silicon Diode

Selenium Cell

Primary Function

barrier layer on selenium
 side of plate prevents
 current from passing from
 the selenium side to the
 aluminum side



TYPICAL SELENIUM CELL DIAGRAM FIGURE 7-15

Silicon Diode

Primary Function

- permits current to flow in only one direction
- provides high current and voltage outputs



TYPICAL SILICON DIODE DIAGRAM

FIGURE 7-16

Basic Electric - Diodes



Current Flows one direction.

Used in rectified systems to change AC to DC with a Rectified diode.

Basic Electric - Rectified diode bridge





Basic Electric Checking the Diode Module

- **D** Place your meter on the diode checker
- Disconnect the structure or ground bed cable
- **Remove the tabs on the course and fine**
- **Do the four part test**

Basic Electric Diode Module Check Four Part Test

- **I** Test across the course and the structure terminal
- **I** Test across the fine and the ground bed terminal
- I Test across the course and the ground bed terminal
- **I** Test across the fine and the structure terminal
- **Reverse all polarities on lead for each test**

Accessory Equipment

- Amp/Volt meters
- Lightning Arresters
- Filters
- Shunts

Accessory Equipment

Amp and Volt meters

 installed to measure and monitor amp and voltage output of rectifier

Lightning Arrestors

- installed on AC input and
 DC output circuits of
 rectifier
- prevent damage to rectifier
 unit during lightning surges

Accessory Equipment

Efficiency Filters

- improve the efficiency of the rectifier
- eliminate electronic noise /interference on electronic circuits
- can also provide lightning protection to the DC side of circuit

Shunts

 provide a way of measuring the output current of the rectifier

Impressed Current Groundbed

- Cast Iron
- Platinum
- ✤ Graphite
- Mixed Metal Oxide
- Coke Breeze

Groundbed Design

- Leave it to the experienced Corrosion Control Engineer
 - Things to consider
 - Right-of-way
 - Soil resistivity
 - Pipe diameter
 - Pipe wall thickness
 - Coating condition and type
 - Proximity to other structures



- ✤ What is a rectifier?
- Can you name the major components of a rectifier?
- What are their functions?

Rectifier Monitoring

Department of Transportation Inspection Requirements

Monitor and Evaluate New and Existing Rectifiers Per CFR-49 Part 192

- Rectifiers inspected
 6(six) times per year not
 to exceed 2.5 months
 between inspections
 - Inspection Includes
 - General Condition of rectifier
 - Recording rectifier DC volts and amps output

- Additional Information
 - readings taken from either rectifier meters
 OR handheld digital meters
 - record all data and changes made

Rectifier Required Inspections

- Importance of Inspections
 - To ensure rectifier unit and ground bed are in good condition



Required Inspections



 Will detect any outside interference problems
 Ensure entire area surrounding rectifier is maintained

Rectifier Inspection Safety Precautions

- Look for presence of insects, rodents or other hazards around rectifier
- Check for electrical shorts by brushing rectifier unit with back of your hand



Rectifier Inspection Safety Precautions

no contact voltage detector









- DC voltage output readings
 - reading DC volts meter on rectifier unit
 - To ensure meter accuracy
 - multimeter is connected in parallel to rectifier output terminals



- DC voltage output readings
 - reading DC volts meter on rectifier unit
 - To ensure meter accuracy
 - multimeter is connected in parallel to rectifier output terminals

- DC Amperage Output reading obtained by
 - Reading DC amps meter on rectifier unit
 - With mtr. On DC amps setting -connect in series to rectifier output terminals
 - ensure rectifier is turned off then on



TWO METHODS:

- 1. DC AMMETER IN SERIES WITH ONE OF THE DC LEGS. CURRENT READ DIRECT IN AMPERES.
- DC MILLIVOLTMETER IN PARALLEL WITH PANEL SHUNT. RATING OF SHUNT WILL USUALLY BE STAMPED INTO THE SHUNT.



 DC amperage output reading also can be obtained by

- connecting multimeter in parallel with panel shunt
- obtain reading and perform calculations

Various types of shunts









Basic Electric - Shunt

- Shunts are resistors; therefore is considered a load.
- Measure voltage across shunt with meter connected in parallel.
- Shunts are used mainly for measuring current flow in a circuit.
 - Rectifiers
 - Bonds

| and ployed | Shunt Rating | | Shunt Value | Shunt Factor |
|------------|--------------|----------------------|--------------------|-----------------|
| | Amps | MV | Ohms | A/mV |
| Holloway T | ype | in the second second | man and the second | Thursday |
| RS | 5 | 50 | .01 | .1 |
| SS | 25 | 25 | .001 | 1 |
| SO | 50 | 50 | .001 | 1 |
| SW or CP | 1 | 50 | .05 | .02 |
| SW or CP | 2 | 50 | .025 | .04 |
| SW or CP | 3 | 50 | .017 | .06 |
| SW or CP | 4 | 50 | .0125 | .08 |
| SW or CP | 5 | 50 | .01 | .1 |
| SW or CP | 10 | 50 | .005 | .2 |
| SW | 15 | 50 | .0033 | .3 |
| SW | 20 | 50 | .0025 | .4 |
| SW | 25 | 50 | .002 | .5 |
| SW | 30 | 50 | .0017 | .6 |
| SW | 50 | 50 | .001 | 1 |
| SW | 60 | 50 | .0008 | 1.2 |
| SW | 75 | 50 | .0067 | 1.5 |
| SW | 100 | 50 | .0005 | 2 |
| J.B. Type | | | | |
| Agra-Mesa | 5 | 50 | .01 | .1 |
| Cott or MC | М | | | |
| Red (MCM) | .1 | 100 | .1 | .01 |
| Red (Cott) | .5 | 50 | .1 | .01 |
| Yellow | 5 | 50 | .01 | .1 |
| Orange | 25 | 25 | .001 | 1 |

1

Table 4.2 Shunt Types and Values

OHM'S Law



- (1) I = E/R
- $(2) \qquad \mathbf{R} = \mathbf{E}/\mathbf{I}$
- $(3) \quad E = I x R \text{ or } E = IR$

I = Current in Amperes E = Voltage in volts R = Resistance in Ohms



Volt

The volt is the basic unit of electrical pressure which forces an electrical current (electrons) to flow through an electrical circuit.

1000 mV = 1 V

1 mV = 0.001 V

SYMBOL is either V or E

| 50 mV5= | V | 2.5 V = | 2 <mark>n5,00</mark> |
|-----------|---|----------|----------------------|
| 250 m¥5≎ | V | 10.0 V = | <u>1ຄ</u> າງ00 |
| 850 m³/5= | V | 3.67 V = | <mark>ന}70</mark> |

OHM'S Law

Sample Calculations:

- $\underline{\mathbf{I}}$ $\underline{\mathbf{V}}$ $\underline{\mathbf{R}}$
- 1. **2** 10 V **5** ohms
- 2. 3A 🔗 ohms
- **3.** 1<u>00 mA</u> (.1 A)10 mV **0.1** ohms
- 4. 1200 mA 12V ____10 ohms



Additional samples provided at the end of the chapter.



SF <u>0.5</u> X 4.2 mV = <u>2.1</u> A





V / R = I

Measurement (V) / R (0.1 Ω , 0.01 Ω , or 0.001 Ω) = I (A)

Measurement of 32.1 mV = .0321 V / 0.1Ω = .321 A

Measurement of 32.1 mV = .0321 V / 0.01Ω = 3.21 A

Measurement of 32.1 mV = .0321 V / 0.001Ω = 32.1 A

Basic Electrical Efficiency Rating Calculation

 $\frac{DC \text{ Watts (Output)}}{AC \text{ Watts (Input)}} = (answer) \cdot 100 = Eff. \text{ Rating \%}$

For example,

Measurement of AC current and AC voltage on the inlet of the transformer. $I_{AE} = P$ (watta) DC Output

$$I \bullet E = P$$
 (watts) DC Output
 $I \bullet E = P$ (watts) AC Input

 $\frac{10 \text{amps} \cdot 20 \text{ Volts} = 200 \text{ Watts}}{20 \text{amps} \cdot 30 \text{ Volts} = 600 \text{ Watts}} = .33 \cdot 100 = 33\%$

Review: Rectifier Inspections

- Observe all safety precautions while performing rectifier inspections !
- Check physical condition of rectifier unit and area surrounding rectifier

- Obtain DC voltage reading and record
- Obtain DC amps reading by either method illustrated
- Record accurate readings on appropriate forms

Additional Information - Annual Inspections

- Clean and tighten all connections
- Clean all screens, vents
- Check all meters for accuracy
- Replace damaged wires

- Check all protective devices - fuses, lightning arresters
- Inspect all components for damage
- Clean rectifier unit of dirt, insects,

Questions?

Thanks!

Contact Information Josh Brewer josh.brewer@isfieldservices.com 989-388-3051